

Operating Instructions

Vacuum Pump EVE-OG 25-40, EVE-OG 63-100

Note

The Operating instructions were originally written in German. Store in a safe place for future reference. Subject to technical changes without notice. No responsibility is taken for printing or other types of errors.

Published by

© J. Schmalz GmbH, 01/25

This document is protected by copyright. J. Schmalz GmbH retains the rights established thereby. Reproduction of the contents, in full or in part, is only permitted within the limits of the legal provisions of copyright law. Any modifications to or abridgments of the document are prohibited without explicit written agreement from J. Schmalz GmbH.

Contact

J. Schmalz GmbH
Johannes-Schmalz-Str. 1
72293 Glatten, Germany
T: +49 (0) 7443 2403-0
schmalz@schmalz.de
www.schmalz.com

Contact information for Schmalz companies and trade partners worldwide can be found at:
www.schmalz.com/salesnetwork

Contents

1 Important Information	5
1.1 Note on Using this Document	5
1.2 The technical documentation is part of the product	5
1.3 Type Plate	5
1.4 Symbols	6
2 Fundamental Safety Instructions	7
2.1 Intended Use	7
2.2 Non-Intended Use	7
2.3 Personnel qualification	7
2.4 Warnings in This Document	8
2.5 Residual Risks	8
2.6 Modifications to the Product	9
3 Product Description	10
3.1 Vacuum Pump Components	10
3.2 Functional Principle	11
3.3 Application Area	11
3.4 On/Off Switch	11
4 Technical Data	12
4.1 General Parameters	12
4.2 Oil	13
5 Transportation and Storage	14
5.1 Checking the Delivery	14
5.2 Transporting the Vacuum Pump	14
5.3 Storage	15
6 Installation	16
6.1 Installation Instructions	16
6.2 Mounting	17
6.3 Pneumatically Connecting the Vacuum Pump	17
6.4 Electrical Connection	19
6.5 Checking the oil level	22
6.6 Filling with Oil	23
7 Operation	24
7.1 Safety Instructions	24
7.2 Conveying Condensable Vapors	25
8 Maintenance	26
8.1 Safety Instructions	26
8.2 Maintenance Plan	26
8.3 Oil and oil filter change	28
8.4 Changing the Air-Oil Separators	30
8.5 Cleaning the Pump	31

9 Warranty 32

10 Repair 33

11 Troubleshooting..... 34

 11.1 Safety Instructions for Troubleshooting..... 34

 11.2 Troubleshooting 34

12 Optional Accessories 37

 12.1 Gas ballast valve..... 37

 12.2 Suction filter..... 37

 12.3 Level Switch..... 37

13 Spare and Wearing Parts 38

14 Accessories..... 39

15 Taking the Product Out of Operation and Disposal..... 40

16 EU Conformity 41

17 Declaration of Decontamination..... 42

1 Important Information

1.1 Note on Using this Document

J. Schmalz GmbH is generally referred to as Schmalz in this document.

The document contains important notes and information about the different operating phases of the product:

- Transport, storage, start of operations and decommissioning
- Safe operation, required maintenance, rectification of any faults

The document describes the product at the time of delivery by Schmalz and is aimed at:

- Installers who are trained in handling the product and can operate and install it
- Technically trained service personnel performing the maintenance work
- Technically trained persons who work on electrical equipment

1.2 The technical documentation is part of the product

1. For problem-free and safe operation, follow the instructions in the documents.
2. Keep the technical documentation in close proximity to the product. The documentation must be accessible to personnel at all times.
3. Pass on the technical documentation to subsequent users.
 - ⇒ Failure to follow the instructions in these Operating instructions may result in life-threatening injuries!
 - ⇒ Schmalz is not liable for damage or malfunctions that result from failure to heed these instructions.


If you still have questions after reading the technical documentation, contact Schmalz Service at:
www.schmalz.com/services

1.3 Type Plate

The type plates (1) and (2) are permanently attached to the Vacuum pump and must always be clearly legible.


The type plate (1) contains the following data:

- Max. vacuum
- Information about oil
- CE label
- EAC label



The type plate (2) contains the following data:

- Part sales designation/type
- Part number
- Manufacturing date
- CE label
- QR code



Please specify all the information above when ordering replacement parts, making warranty claims or for any other inquiries.

1.4 Symbols



This symbol indicates useful and important information.

- ✓ This symbol represents a prerequisite that must be met before an action is performed.
- ▶ This symbol represents an action to be performed.
- ⇒ This symbol represents the result of an action.

Actions that consist of more than one step are numbered:

1. First action to be performed.
2. Second action to be performed.

2 Fundamental Safety Instructions

2.1 Intended Use

The vacuum pump from Schmalz is designed for the suction of air and other dry, non-aggressive, non-toxic and non-explosive gases.

Neutral gases in accordance with EN 983 are approved as evacuation media. Neutral gases include air, nitrogen and inert gases (e.g. argon, xenon and neon).

Conveying other media increases the thermal and/or mechanical load on the machine and therefore requires prior consultation with J. Schmalz.

The vacuum pump is designed for indoor use; in the case of outdoor installation, contact Schmalz so that special precautions can be taken if necessary.

The machine is resistant to the final pressure.

Note: The non-return valve (NRV) on the machine should not be used as a system non-return or shut-off valve. The non-return valve serves only to protect the machine.

If the machine is to be maintained following deactivation:

- ▶ Install a manually or automatically activated valve (= non-return valve) in the suction line.

You can find the permitted environmental conditions in the technical data.

The product is built in accordance with the latest standards of technology and is delivered in a safe operating condition; however, hazards may arise during use.

The product is intended for industrial use.

Intended use includes observing the technical data and the installation and operating instructions in this manual.

2.2 Non-Intended Use

In particular, the following are considered non-intended use:

- Operation in a potentially explosive atmosphere (ATEX).
- Connection to a potentially explosive atmosphere (ATEX).
- The conveyance of any other gases (except air), in particular hazardous substances, is not permitted and is prohibited.
- Use as a climbing aid

2.3 Personnel qualification




Unqualified personnel cannot recognize dangers and are therefore exposed to higher risks!

1. Electrical work and installations may only be carried out by qualified electrical specialists.
2. Assembly and adjustment work may only be carried out by qualified personnel.

These operating instructions are intended for fitters who are trained in handling the product and who can operate and install it.

2.4 Warnings in This Document

Warnings warn against hazards that may occur when handling the product. The signal word indicates the level of danger.

Signal word	Meaning
 DANGER	Indicates a high-risk hazard that will result in death or serious injury if not avoided.
 WARNING	Indicates a medium-risk hazard that could result in death or serious injury if not avoided.
 CAUTION	Indicates a low-risk hazard that could result in minor or moderate injury if not avoided.
NOTE	Indicates a danger that leads to property damage.

2.5 Residual Risks



WARNING

Risk of fire and explosion caused by sparks

Serious injury!

- ▶ Do not use the product in environments where there is a risk of explosion.



CAUTION

Vacuum close to the eye

Severe eye injury!

- ▶ Wear eye protection.
- ▶ Do not look into vacuum openings, e.g. suction cups.



WARNING

Extraction of hazardous media, liquids or bulk material

Personal injury or damage to property!

- ▶ Do not extract harmful media such as dust, oil mists, vapors, aerosols etc.
- ▶ Do not extract aggressive gases or media such as acids, acid fumes, bases, biocides, disinfectants or detergents.
- ▶ Do not extract liquids or bulk materials, e.g. granulates.



CAUTION

Falling product

Risk of injury

- ▶ Securely attach the product at the site of operation.
- ▶ Wear safety shoes (S1) and safety glasses when handling and mounting/dismounting the product.


2.6 Modifications to the Product

Schmalz assumes no liability for consequences of modifications over which it has no control:

1. The product must be operated only in its original condition as delivered.
2. Use only original spare parts from Schmalz.
3. The product must be operated only in perfect condition.


3 Product Description

3.1 Vacuum Pump Components



1	Oil filter	2	Motor terminal box
3	Type plate	4	Oil separator
5	Air-oil separator	6	Suction connection
7	Exhaust air connection	8	Axial fan
9	Oil drain screw	10	Oil sight glass
11	Oil filler plug	12	Gas ballast valve
13	Eye bolt	—	—

3.2 Functional Principle



The vacuum pump functions according to the rotary vane principle.

The oil seals the gaps, lubricates the slides and dissipates compression heat.

To prevent the vacuum pump from turning backward following deactivation, it must be fitted with a non-return valve RSV (NRV=NonReturnValve).

To prevent the entry of solids, the vacuum pump is fitted with an intake screen (IS).

The oil filter cleans the circulating oil.

Air-oil separators then separate the oil from the discharged gas.

3.3 Application Area

Version with float valve (standard):

The machine is suitable for continuous operation.

Version with oil return valve:

During operation, oil collects at the bottom of the upper chamber of the oil separator and cannot flow into the lower chamber during machine operation.

When operating the machine with low vacuum, proceed as follows after ten hours of continuous machine operation near the final pressure:

- ▶ Switch off the machine for at least 15 minutes.
- ⇒ This allows the oil to flow from the upper chamber of the oil separator to the lower chamber.

3.4 On/Off Switch

The vacuum pump is supplied without an on/off switch. The vacuum pump must be controlled at the site of installation.

The machine can be fitted with a soft-starter.

4 Technical Data

4.1 General Parameters

Oil-lubricated rotary vane vacuum pump:

Parameter	Unit	EVE-OG 25	EVE-OG 40
Nominal suction rate (50 Hz / 60 Hz)	m ³ /h	25 / 30	40 / 48
Max. vacuum (without gas ballast valve)	mbar abs.	0.1 to 0.5	
Max. vacuum (with gas ballast valve)	mbar abs.	0.5 to 1.5	
Motor rated speed (50 Hz / 60 Hz)	rpm	1500 / 1800	
Motor rated power (50 Hz / 60 Hz)	kW	1.0 / 1.2	1.4 / 1.7
Power consumption at 100 mbar (50 Hz / 60 Hz)	kW	0.8 / 0.9	1.1 / 1.2
Power consumption at final pressure (50 Hz / 60 Hz)	kW	0.5 / 0.6	0.6 / 0.7
Sound pressure level (EN ISO 2151) (50 Hz / 60 Hz)	dB(A)	60 / 63	63 / 66
Max. water vapor compatibility (with gas ballast valve)	hPa (mbar)	40	
Water vapor capacity (with gas ballast valve)	kg/h	0.9	1.1
Ambient temperature range	° C	5 to 40 *	
Gas inlet temperature range	° C	5 to 40 *	
Ambient pressure	—	Atmospheric pressure	
Oil quantity	l	1.0	
Weight approx.	kg	40	45

* If the temperatures are higher or lower, please contact Schmalz Service.

Parameter	Unit	EVE-OG 63	EVE-OG 100
Nominal suction rate (50 Hz / 60 Hz)	m ³ /h	63 / 76	100 / 120
Max. vacuum (without gas ballast valve)	mbar abs.	0.1 to 0.5	
Max. vacuum (with gas ballast valve)	mbar abs.	0.5 to 1.5	
Motor rated speed (50 Hz / 60 Hz)	rpm	1500 / 1800	
Motor rated power (50 Hz / 60 Hz)	kW	2.0 / 2.4	2.7 / 3.4
Power consumption at 100 mbar (50 Hz / 60 Hz)	kW	1.3 / 1.5	1.9 / 2.4
Power consumption at final pressure (50 Hz / 60 Hz)	kW	0.7 / 0.8	1.2 / 1.5
Sound pressure level (EN ISO 2151) (50 Hz / 60 Hz)	dB(A)	64 / 67	65 / 68
Max. water vapor compatibility (with gas ballast valve)	hPa (mbar)	40	
Water vapor capacity (with gas ballast valve)	kg/h	1.8	2.8
Ambient temperature range	° C	5 to 40 *	
Gas inlet temperature range	° C	5 to 40 *	
Ambient pressure	—	Atmospheric pressure	
Oil quantity	l	2.0	
Weight approx.	kg	55	75

* If the temperatures are higher or lower, please contact Schmalz Service.

GBV = gas ballast valve

For exact electrical and pneumatic data, refer to the type plate and/or data sheet.

4.2 Oil

Description	Value
Designation	OEL-EVE-ANDEROL 555
ISO-VG	100
Basis	Synthetic diester
Ambient temperature range [°C]	5 to 40
Part no. for 1 L packaging	27.02.01.00055
Part no. for 5 L packaging	27.02.01.00056

The type plate displays the type of oil used to fill the vacuum pump.

5 Transportation and Storage

5.1 Checking the Delivery

The scope of delivery can be found in the order confirmation. The weights and dimensions are listed in the delivery notes.

1. Compare the entire delivery with the supplied delivery notes to make sure nothing is missing.
2. Damage caused by defective packaging or occurring in transit must be reported immediately to the carrier and J. Schmalz GmbH.

5.2 Transporting the Vacuum Pump

- ✓ Wear protective work shoes and gloves.
1. Secure the load according to national regulations before every transport operation.
 2. Ensure that the hoists and slings used have the necessary specifications.
 3. Ensure that any personnel involved in transporting with lifting devices or industrial trucks are authorized and qualified to do so.



WARNING

Suspended load

Risk of injury!

- ▶ Do not walk, stand or work under suspended loads.



WARNING

Lifting the vacuum pump from the eye bolt of the motor

Risk of serious injury!

- ▶ Do not lift the vacuum pump by the eye bolt of the motor, but rather as illustrated above.



CAUTION

Moving or carrying the product by hand.

Risk of injury!

- ▶ Do not lift products that weigh more than 20 kg by hand.
- ▶ Observe all safety regulations to protect against accidents.
- ⇒ E.g. wear PPE (gloves, safety shoes, helmet)




NOTE

Tilting a vacuum pump filled with oil

Tilting a vacuum pump filled with oil can cause large quantities of oil to enter the cylinder. The slides will be damaged if the vacuum pump is started while there is an excessive amount of oil in the cylinder. This will destroy the vacuum pump.

- ▶ Before transporting, always drain the oil or transport the vacuum pump in a horizontal position.



- ✓ The eye bolt must be in perfect condition, completely screwed in, and hand-tightened.
- ▶ Check the vacuum pump for transport damage.

If the vacuum pump is mounted on a base plate, proceed as follows:

- ▶ Remove the mounting.

Before the start of operations, check and top up the oil in the pump according to the indication on the oil level indicator.



Commissioning the vacuum pump without sufficient oil will destroy it.

5.3 Storage

- ▶ Seal all openings with adhesive tape or reuse the caps included in delivery.

Proceed as follows if storing for longer than 3 months:

1. Wrap the vacuum pump with anti-corrosive plastic film.
2. Store the vacuum pump in a protected, dry and dust-free room, preferably in its original packaging and at a temperature between 0 and 40° C.

6 Installation

6.1 Installation Instructions



⚠ CAUTION

Improper installation or maintenance

Personal injury or damage to property

- ▶ Prior to installation and before maintenance work, the vacuum generator must be disconnected from the power supply and secured against unauthorized restart!




NOTE

Using the Vacuum pump outside the permissible installation conditions.

Danger of premature failure of the machine and loss of efficiency.

- ▶ The installation conditions must comply with all specifications.



To ensure safe installation, observe the following instructions:

- ✓ The machine must not be in a potentially explosive environment.
 - ✓ The ambient conditions must comply with the specifications contained in the technical data.
 - ✓ The installation site must be ventilated to ensure sufficient cooling of the machine.
 - ✓ The oil sight glass must be visible at all times.
 - ✓ Sufficient space for maintenance work must be provided.
1. Ensure that the environmental conditions comply with the motor protection class and electrical devices.
 2. Ensure that the installation space or location is protected from the influences of weather and lightning strikes.

3. Ensure that the ventilation openings (inlets and outlets) are not covered and that the cooling air can flow freely.
4. Check the oil level.
5. Ensure that all covers, guards, etc. are attached.
6. Use only the connectors, mounting holes and attachment materials that have been provided.
7. Firmly connect and secure pneumatic and electrical line connections to the vacuum generator.

If the vacuum pump is installed higher than 1,000 meters above sea level:

- ▶ Contact a Schmalz representative. The motor power must be limited or the ambient temperature must be restricted.

6.2 Mounting

Before mounting the pump at the installation location, bring it to the ambient temperature.

1. Ensure that the machine is set up and attached horizontally. A deviation of 1° in any direction can be tolerated.
2. Remove all protective caps before installation.

Tension or pressure must not be applied to the connections via the connection lines. If necessary, use flexible connections.

The line cross-section of the connection lines must have at least the same cross-section as the machine connections over the entire length.

If the connection lines are very long, it is advisable to use larger line cross-sections to avoid loss of efficiency. Contact a Schmalz representative.

6.3 Pneumatically Connecting the Vacuum Pump



CAUTION

The discharged gas contains minimal amounts of oil.

Health risk

- ▶ If the air is directed into rooms where people are present, ensure adequate ventilation.



NOTE

Ingress of foreign bodies or liquids

Risk of damage to the machine.


- ▶ If the gas that is sucked in contains dust or other solids, install a suitable filter (≤ 5 microns) in front of the inlet of the machine.

Use only hoses that are designed for the maximum permitted pump operating pressure (see the chapter "Technical Data"). Use only hoses that have sufficient chemical resistance to the gases to be conveyed.

Connecting the suction connection:**⚠ WARNING****A powerful vacuum flow creates a strong suction effect**

Risk of injury to eyes or other body parts

- ▶ Wear eye protection.
- ▶ Do not look or reach into the vacuum opening.
- ▶ When the vacuum generator is switched on, maintain a safe distance from the vacuum opening.



1. Remove the protective plug.
2. Connect the suction line to the suction connection (1). The connection size is: – G1 1/4"
3. Check that the hoses and junctions are connected correctly and tightly.
4. Check that the installation is sealed tight.

The connection dimensions may vary depending on the specific configurations.

If the machine is used as part of a vacuum system:

- Schmalz recommends installing a shut-off valve to ensure that the machine cannot run in the reverse direction.
- Schmalz recommends installing a shut-off valve to ensure that no oil can flow back into the vacuum system.

Connecting the exhaust air connection:

1. Remove the protective plug.
2. Connect the exhaust air line to the exhaust air connection (2):
The connection size is:
— 1x G1 1/4" ▶ For variant 25/40
— 2x G1 1/4" ▶ For variant 63/100
3. Check that the hoses and junctions are connected correctly and tightly.
4. Check that the installation is sealed tight.

The connection dimensions may vary for specific orders.

- ▶ Ensure that the discharged gas can flow out freely. Never close the exhaust air line, throttle it or use it as a source of compressed air.

If the air that was sucked in is not discharged into the environment around the immediate vicinity of the vacuum pump, observe the following:

- ▶ Lay the exhaust air line sloping down to the vacuum pump or install a liquid condenser or a condensation collector pipe with a drain valve to prevent liquid from running back into the machine.

6.4 Electrical Connection



⚠ DANGER

Electrocution by live components or wires

Serious injury or death!

- ▶ Electrical installation work may only be carried out by qualified personnel.
- ▶ Make sure that the electrical components are not live before installation, maintenance and troubleshooting.
- ▶ Switch off the mains switch and secure against unauthorized restart.

The electrical installation must comply with applicable national and international standards, guidelines and regulations.

- ✓ The power supply for the motor must comply with the specifications on the motor type plate.
1. Install a lockable disconnecting switch on the power supply so that the vacuum pump can be completely disconnected during maintenance operations.
 2. Install overload protection for the motor according to EN 60204-1. (Schmalz recommends installing a D-curve circuit breaker).
 3. Ensure that the vacuum pump motor is not affected by electrical or electromagnetic pulses from the power supply.
 4. Connect the protective conductor.
 5. Connect the motor to the power supply.




NOTE

Incorrect electrical connection of the vacuum pump

Danger of motor damage.


- ▶ The following circuit diagrams show the typical wirings. Check that the motor terminal box contains instructions for the cabling/circuit diagrams.

6.4.1 Circuit diagram for single-phase motor




6.4.2 Circuit diagrams for three-phase motor


Delta connection (low voltage):




Star connection (high voltage):



Double star connection, multi-voltage motor with 9 pins (low voltage):



Star connection, multi-voltage motor with 9 pins (high voltage):



6.4.3 Checking the Direction of Rotation



NOTE


Electric motor running in the wrong direction

Damage to the motor

- ▶ Reverse the rotational direction by reversing the polarity in the supply line.

For three-phase A.C. motors, check the direction of rotation of the motor as follows:

1. Switch on the vacuum pump for a fraction of a second.
2. Watch the motor's fan blade. It must rotate in the direction shown by the arrow on the motor housing.
3. The device is delivered with a clockwise rotation field. If the direction of rotation is incorrect, switch the unit off immediately and reverse the connection in the supply line.
4. Check the direction of rotation once again.



Damage or destruction of the motor resulting from operation with the incorrect rotational direction is not covered by the warranty.

6.4.4 Optional: Electrical Connection of Monitoring Systems



To prevent possible false alarms, Schmalz recommends that a delay of at least 20 seconds be configured in the control system.

Circuit diagram for level switch (optional)

Electrical data:

$U = \text{max. } 250 \text{ V}$

$I_{\text{max}} = 1.0 \text{ A}$

$P = 20 \text{ W}$

IP 65

Switching element function:


Reed contact

Contact: 2x normally open (NO)

Switching point:


$S1_{\text{trip}} \triangleright \text{pin } 1 + 2 \triangleright \text{max. level}$

$S1_{\text{trip}} \triangleright \text{pin } 3 + 4 \triangleright \text{max. level}$



6.5 Checking the oil level

1. Switch off the vacuum pump.
2. After switching off the vacuum pump, wait 1 minute before checking the oil level.
3. If necessary, top up with oil as described in ([See ch. 6.6 Filling with Oil, p. 23](#)).



6.6 Filling with Oil




NOTE

Use of unsuitable oil or too little oil.

Danger of premature failure and damage to the vacuum pump.

- ▶ Only use oils approved and recommended by Schmalz.
- ▶ Maintain the oil level between the MIN and MAX marks.



1. Loosen and remove the oil filler plug.
2. Fill the oil with a funnel; monitor the fill level when doing so.
3. Mount the oil filler plug with an O-ring and tighten with a torque of 12 Nm.

7 Operation

7.1 Safety Instructions



CAUTION

Touching hot surfaces

Touching hot surfaces may cause injury from burns.

- ▶ Wear work gloves.
- ▶ Do not touch components during operation.
- ▶ Allow the components to cool down before commencing work on the product.



CAUTION

Noise pollution caused by machine during operation

Danger of hearing damage

- ▶ If you spend longer periods of time in the immediate vicinity of the machine when it is not soundproofed: Wear ear protectors.



NOTE

Use of unsuitable oil or too little oil.

Danger of premature failure and damage to the vacuum pump.

- ▶ Only use oils approved and recommended by Schmalz.
- ▶ Maintain the oil level between the MIN and MAX marks.

- ▶ Switch on the machine.

The permitted maximum number of starts of 30 times per hour must not be exceeded. The individual starts must be distributed over the period of one hour.

- ▶ Check the oil level after a few minutes of machine operation and top up oil if necessary.

Once the machine is operating under normal conditions, proceed as follows:

- ▶ Measure the motor current consumption and record it for reference purposes for future maintenance and troubleshooting.

7.2 Conveying Condensable Vapors



CAUTION


Condensation blows off while operating and/or venting the machine. The discharged gasses and or fluids can reach temperatures above 70 °C!

Risk of injury from burns!

- ▶ Avoid direct contact with the gas flow and/or fluids.

A certain amount of water vapor in the gas flow is tolerated. Contact Schmalz for information on how to convey other vapors.

When conveying condensable vapors, observe the following:



*Not included in the scope of delivery.

**May be an optional piece of equipment for some products

The gas ballast valve (optional) must be open.

8 Maintenance

8.1 Safety Instructions

1. Work on electrical equipment must be carried out only by qualified electrical specialists.



⚠ WARNING

Machine contaminated with hazardous material.

Danger of poisoning. There is a risk of infection.

- ▶ Wear appropriate personal safety equipment.



⚠ CAUTION

Touching hot surfaces

Touching hot surfaces may cause injury from burns.

- ▶ Wear work gloves.
- ▶ Do not touch components during operation.
- ▶ Allow the components to cool down before commencing work on the product.



⚠ CAUTION

Failure to properly maintain the machine.

Risk of injury!

Risk of premature machine failure and loss of efficiency.

- ▶ Observe the maintenance intervals or contact your Schmalz representative. He or she will be glad to help you.

1. Switch off and lock the vacuum pump to prevent unintentional activation.
2. Vent all connected lines to the atmospheric pressure.
3. If necessary, disconnect all connections.

8.2 Maintenance Plan

The maintenance intervals are very dependent on the individual operating conditions. The intervals provided below should be considered guidelines and individually shortened or extended.

It may be necessary to significantly shorten the maintenance intervals, particularly in the case of a heavy workload, high dust exposure in the environment or the process gas, or other contamination, or the ingress of process material.

Maintenance work	Interval	
	Normal use	Heavy workload
<ul style="list-style-type: none"> ▶ Check the oil level. 	Daily	
<ul style="list-style-type: none"> ▶ Check the vacuum pump for leaking oil. If there is a leak, have the vacuum pump repaired by Schmalz. <p>If a suction filter is installed, observe the following:</p> <ul style="list-style-type: none"> ▶ Check the suction filter insert and replace it if necessary. 	Monthly	
<ul style="list-style-type: none"> ▶ Replace the oil, oil filter, and air-oil separators and exhaust gas filter. 	After max. 4,000 hours or 1 year at the latest	After max. 2,000 hours or 6 months at the latest
<ul style="list-style-type: none"> ▶ Clean dust and contamination from the vacuum pump. <p>If a gas ballast valve is installed, observe the following:</p> <ul style="list-style-type: none"> ▶ Clean the gas ballast valve filter. <p>If the vacuum pump is equipped with an air-oil heat exchanger:</p> <ul style="list-style-type: none"> ▶ Check and/or clean the air-oil heat exchanger. 	Every 6 months	
<ul style="list-style-type: none"> ▶ Perform a general overhaul of the vacuum pump (contact Schmalz). 	Every 5 years	

8.3 Oil and oil filter change






NOTE

Use of unsuitable oil or too little oil.



Danger of premature failure and damage to the vacuum pump.

- ▶ Only use oils approved and recommended by Schmalz.
- ▶ Maintain the oil level between the MIN and MAX marks.





8.4 Changing the Air-Oil Separators



8.5 Cleaning the Pump

- ✓ Pump or drive disconnected from the power supply and free of voltage
- ✓ Pump free of hazardous substances
- ✓ Hoses removed from the pump head
- ▶ If necessary, clean the exterior of the pump using a dry cleaning cloth. Do not use solvents during cleaning work because they may affect plastic parts.

9 Warranty

IMPORTANT!

A warranty claim can only be accepted by Schmalz if the pump has been installed and used in accordance with its corresponding operating instructions. In the case of inappropriate handling or use of force, any warranty and liability claims shall be void.

Damage and defects resulting from inadequate maintenance and cleaning, improper use, repair or attempted repair by unauthorized persons, as well as damage and defects resulting from alterations or modifications to the pump and from replaced parts or materials that do not conform to the original specification are excluded from the warranty.

10 Repair



NOTE

Improper assembly

There is a risk of premature failure of the machine.

Loss of efficiency.

- ▶ We recommend that any disassembly of the machine that goes beyond the procedures described in these operating instructions be carried out by Schmalz.



WARNING

Machine contaminated with hazardous material.

Danger of poisoning. There is a risk of infection.

- ▶ Wear appropriate personal safety equipment.

If the vacuum pump was used to convey gas contaminated with foreign substances that are hazardous to health, proceed as follows:

- ▶ Decontaminate the vacuum pump to the greatest degree possible and indicate the contamination status on a "Decontamination Declaration" (> [See ch. 17 Declaration of Decontamination, p. 42](#)).

Schmalz only accepts vacuum pumps accompanied by a completely filled out and legally-binding, signed "Declaration of Contamination."

11 Troubleshooting

11.1 Safety Instructions for Troubleshooting



⚠ DANGER

Electrocution by live components or wires

Serious injury or death!

- ▶ Electrical installation work may only be carried out by qualified personnel.
- ▶ Make sure that the electrical components are not live before installation, maintenance and troubleshooting.
- ▶ Switch off the mains switch and secure against unauthorized restart.




⚠ CAUTION

Touching hot surfaces

Touching hot surfaces may cause injury from burns.

- ▶ Wear work gloves.
- ▶ Do not touch components during operation.
- ▶ Allow the components to cool down before commencing work on the product.

11.2 Troubleshooting



1	Float valve	2	Air-oil separators
3	Inlet screen	4	Gas ballast valve
5	Coupling	6	Oil filter

Fault	Cause	Troubleshooting
The vacuum pump does not start	The required voltage is not applied to the motor.	▶ Check the power supply.
	The motor is faulty.	▶ Replace the motor.
	The coupler is faulty.	1. Replace the coupler. 2. Fill with oil.
The normal pressure cannot be generated at the suction connection.	The oil level is too low.	▶ Fill with oil.
	The inlet screen is partially clogged.	▶ Clean the inlet screen.
	The air filter insert (optional) is partially clogged.	▶ Replace the air filter insert.
	Internal components are worn or damaged.	▶ Have the vacuum pump repaired by Schmalz.
Too much noise is generated during operation of the vacuum pump.	The coupler is worn.	▶ Replace the coupler.
	The slides are stuck.	▶ Have the vacuum pump repaired by Schmalz.
	The bearings are faulty.	
Too much heat is generated during operation of the machine.	Cooling is insufficient.	1. Clean dust and contamination from the vacuum pump. 2. Check the cooling fan.
	The ambient temperature is too high.	▶ Observe the permissible ambient temperature.
	The oil level is too low.	▶ Fill with oil.
	The air-oil separators are partially clogged.	▶ Replace the air-oil separators.
Vapors and/or drops of oil escape from the gas outlet.	The air-oil separators are partially clogged.	▶ Replace the air-oil separators.
	Air-oil separators and O-ring-rings are not properly installed.	▶ Correctly position the air-oil separators and O-rings.
	The float valve does not function properly.	▶ Check if the float valve and/or oil line are clogged. Remove the clog.
	Version with oil return valve: The machine is in a state of continuous operation for more than 10 hours.	▶ Briefly switch off the vacuum pump at regular intervals (version with oil return valve).
Abnormal oil consumption.	Oil leaks.	▶ Replace the seals (contact Schmalz).
	The float valve does not function precisely.	▶ Check the float valve and the oil return line and replace if necessary (contact Schmalz).
	The vacuum pump runs for a long time at atmospheric pressure.	▶ Ensure that the vacuum pump in the vacuum is ready for operation.
The oil is black.	The period of time between oil changes is too long.	▶ Rinse the vacuum pump. Contact a Schmalz representative about this.
	The air filter (optional) is faulty.	▶ Replace the air filter.
	Too much heat is generated during operation of the vacuum pump.	▶ Refer to "Too much heat is generated during operation of the machine."
The oil is emulsified.	Fluids of vapors were sucked into the vacuum pump in large quantities.	1. Rinse the vacuum pump. Contact a Schmalz representative about this. 2. Clean the gas ballast valve filter. 3. Change the operating mode (refer to "Conveying Condensable Vapors").

Malfunction cannot be corrected!

If you cannot identify any of the listed causes, send the pump to the Schmalz customer service (see the first page for the address).

1. Disconnect the power supply and remove the pump
2. Clean the pump ([> See ch. 8.5 Cleaning the Pump, p. 31](#))
3. Send the pump to Schmalz together with the completed declaration of decontamination ([\(> See ch. 17 Declaration of Decontamination, p. 42\)](#)) and the specification of the conveyed medium.


12 Optional Accessories

12.1 Gas ballast valve

The gas ballast valve is used to add a finite amount of ambient air to the process gas in order to counteract steam condensation in the machine.

The gas ballast valve reduces the value of the maximum vacuum of the vacuum pump.

See also

 General Parameters [► 12]

12.2 Suction filter

The suction filter protects the machine from dust and other solids in the process gas. The suction filter is available with a paper or polyester filter insert.

12.3 Level Switch

The level switch monitors the oil level in the oil separator.

13 Spare and Wearing Parts



NOTE

Use of non-original (non-Schmalz) spare parts.

Danger of premature failure of the machine and loss of efficiency.

- ▶ The exclusive use of original spare parts is a prerequisite for the proper functioning of the system and for the validity of the warranty.

The following list contains the primary spare and wearing parts.

Type	Description	Part no.	Legend
VST EVE-OG-25-40, pump wearing parts set (for var. 25/40)	All required parts for maintenance are included.	10.03.02.00060	W
FILT-EINS 3 65x70 PAP STF-3/4-IG (for var. 25)	Filter cartridge for additional filter	10.07.01.00017	S
FILT-EINS 3 98x70 PAP STF-1-1/4-IGN (for var. 40/63/100)	Filter cartridge for additional filter	10.07.01.00018	S
VST EVE-OG-63-100, pump wearing parts set (for var. 63/100)	All required parts for maintenance are included.	10.03.02.00055	S
OEL-EVE-OG-1	Replacement oil for vacuum pumps 1.00 L	27.02.01.00055	W

Legend: | Spare part = S | Wearing part = W

If other spare parts are required, proceed as follows:

- ▶ Request the detailed spare parts list from your Schmalz representative.

14 Accessories

Designation	Part no.	Note
Pressure gauge DRM 40 P1 H	10.07.02.00050	—
Motor-protection switch with housing MSS-K 2.5-4A	10.04.04.00120	For var. 25/40
Motor-protection switch with housing MSS-K 4-6.3A	10.04.04.00121	For var. 63
Motor-protection switch with housing MSS-K 6.3-10A	10.04.04.00122	For var. 100

15 Taking the Product Out of Operation and Disposal

Only qualified specialist staff may prepare the product for disposal.

Taking the product out of operation

1. Switch off and lock the machine to prevent it from being switched on accidentally.
2. Vent all connected lines to the atmospheric pressure.
3. Disconnect all connections.

Disassembly and disposal

1. Drain the oil.
2. Remove the air-oil separators.
3. Remove the oil filter.
4. Separate hazardous waste from the machine.
5. Dispose of hazardous waste in accordance with applicable legal regulations.
6. Dispose of the machine as scrap metal.

For proper disposal, contact a company specializing in the disposal of technical goods and instruct the company to observe the applicable disposal and environmental regulations.

16 EU Conformity

EU Declaration of Conformity

The manufacturer Schmalz confirms that the vacuum pump EVE-OG described in these operating instructions fulfills the following applicable EU directives:

2006/42/EC	Machinery Directive
2014/30/EU	Electromagnetic Compatibility
2011/65/EU	RoHS Directive

The following harmonized standards were applied:

EN ISO 12100	Safety of machinery — General principles for design — Risk assessment and risk reduction
EN ISO 13857	Safety of Machinery – Safety distances to prevent hazard zones being reached by upper and lower limbs
EN 1012-2: 1996 +A1:2009	Compressors and Vacuum Pumps - Safety requirements - Part 2: Vacuum pumps
EN ISO 2151	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN 60204-1+A1+AC	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN 61000-6-2+AC	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
EN 61000-6-4+A1	Electromagnetic compatibility - Part 6-4: Generic standards - Emission standard for industrial environments



The EU Declaration of Conformity valid at the time of product delivery is delivered with product or made available online. The standards and directives cited here reflect the status at the time of publication of the operating and assembly instructions.

17 Declaration of Decontamination

- ✓ A customer certificate regarding the conveyed medium and pump cleaning (declaration of decontamination) is a prerequisite for Schmalz to repair the pump.
- ▶ **Copy** this page. Enter the pump model, serial number and the conveyed medium in the form below and send the signed form to the Schmalz customer service together with the flushed and cleaned pump.

J. Schmalz GmbH
Customer service
Johannes-Schmalz-Str. 1
72293 Glatten, Germany

Customer Declaration of Decontamination for the Repair Order

We confirm that the following media were conveyed with the pump listed below and that the pump has been flushed and cleaned.

Pump model	
Serial number	
Conveyed media	Medium 1 ...
	Where applicable, medium 2 ...
	Where applicable, medium 3 ...
	Where applicable, medium 4 ...
	Where applicable, medium 5 ...

There are no aggressive, biological, radioactive, poisonous or other hazardous media in the pump.

Company

Date/signature

At Your Service Worldwide



Vacuum automation

WWW.SCHMALZ.COM/AUTOMATION

Handling systems

WWW.SCHMALZ.COM/EN-US/VACUUM-LIFTERS-AND-CRANE-SYSTEMS

J. Schmalz GmbH

Johannes-Schmalz-Str. 1
72293 Glatten, Germany
T: +49 (0) 7443 2403-0
schmalz@schmalz.de
WWW.SCHMALZ.COM